

Accessories - Lens Pen

509884 Double Ended Lens Pen

Double-ended cleaning pen with a lens brush at one end, and a special velvet pad with a non-toxic chemical compound at the other.

- Suitable for all camera lenses, Binoculars and LCD Screens
- Perfectly safe for coated or non-coated lenses. Pad is contaminant free
- The brush can be withdrawn into the body of the pen
- The pad cover is used to protect and with a twist, clean the pad.

